

HERITAGE

TRADITIONAL BUILDING PRODUCTS

46-48 Doury Rd, Ballymena BT43 6JB

Tel: +44 (0)28 2568 5055 Fax: +44 (0)28 2568 5831

Website: www.heritageltd.com Email: info@heritageltd.com

Applying lime to plasterboard ceiling

Whilst not a traditional finish, sometimes as specifiers, you may require a lime skim finish to be applied to a gypsum plasterboard ceiling.

Preparation

Tape the joints etc. according to normal good practice. Ensure that there are no gaps between sheets as this will lead to cracking of the skim coat once applied.

Substrate should be clean and dry, with no loose parts or flaking areas. All dirt and dust should be removed.

Application

Once prepared, Decorative Precoat Bayosan DG 27 should be applied (refer to technical information sheet).

Once applied, this coat should be allowed to dry for 12-24hrs (depending on site specific conditions). A further coat can then be applied and left to go 'tacky' before receiving lime skim finish coat.